



UV Filter Standard Face Shields (I005-002, I005-072)
UV Filter Standard Face Shield Replacements (I005-074, I005-073)
UV Filter Deluxe Face Shields (I005-070, I005-075)
UV Filter Deluxe Face Shield Replacements (I005-071, I005-076)

UV Process Supply Face Shields offers unrestricted movement, comfort, and safety while providing protection against airborne particles and liquid splash. Features adjustable ratcheting headgear and pivot locks for visor. Injection molded visor is .060" thick and meets or exceeds ANSI Z87.1 standards.

Standard replacement shields are 8" x 12" x .060" and are formed to a 4" radius. The attachment pattern is a series of slots designed to fit a large variety of headgear. Standard Face Shields are formed to a radius to maintain their shape without distortion and meets or exceeds ANSI Z87.1 standards.

WARNING:
FOR YOUR OWN PROTECTION, READ INSTRUCTIONS COMPLETELY BEFORE USING.
FACE SHIELDS DO NOT COME WITH A WARRANTY.
FACE SHIELDS DO NOT PROVIDE UNLIMITED EYE PROTECTION.

Safety face shields may not protect you against severe impact hazards such as fragmenting grinding wheels, explosive devices, molten metal, arc/gas welding radiation, or heavy liquid splash.

Additional eye protection may be required in the following circumstances:

1. Safety glasses or goggles are needed where impact hazards exist.
2. Proper goggles are needed where liquid splash hazards exist.
3. Additional eye protection may be needed to block blue light hazard (400-510nm) in certain UV applications. SAF-T-CURE® Orange UV Filter Glasses (I005-017) provide such protection.

To prevent serious eye injury, check with your supervisor or safety personnel to be sure you are being provided with adequate eye protection for your application.

Pitted, scratched, cracked, or cloudy lenses impair vision and reduce impact protection. Always replace pitted, scratched, cracked, or cloudy lenses immediately. Inspect before each use and replace worn or damaged parts.

CLEANING:

1. Wash with mild detergent and warm water. **DO NOT USE SOLVENTS!**
2. Rinse clean and wipe dry with soft tissue or cloth.

IMPORTANT:

To the best of our knowledge, this information and our recommendations for the use of these products are based on information believed to be reliable. Everyone intending to use these products should verify that they are adequate for the application and comply with appropriate health requirements. Since use of these products is beyond our control, no warranty can be made, expressed, or implied, as to the effects of such use, or the results to be obtained.

UV Process Supply, Inc.
1229 W Cortland St, Chicago, IL 60614-4805
773-248-0099, fax 773-880-6647
www.uvprocess.com
info@uvprocess.com